


## MICROWAVE MOTION SENSOR USER'S MANUAL Model No.: MC004S



75.00	
82.00	
	(Unit: mm)

75 00


Technical Specifications		
Input voltage	220/240Vac 50Hz	
Rated load	400W(Inductive load), 800W(Resistive load)	
Detection area	0.5~8m, adjustable	
Hold time	10s / 30s / 90s / 3min / 20min / 30min	<b>(€</b> 0700
Daylight sensor	5lux / 10lux / 30lux / 50lux / Disable	
Sensor principle	Microwave motion detector	
Microwave frequency	5.8GHz±75MHz, ISM wave band	
Transmitting power	<0.5mW (1% of transmitting power for cell phone)	
Detection range	Max. (Φ x h): 16m x 4m	
Detection angle	150°(Wall installation),	
	360°(Ceiling installation)	
Motion detection	0.5~3m/s	R&TTE
Operating temperature	-10°C~60°C	
IP rating	IP20	

## General Guidelines for Installation



- 1, The sensor should be installed by a qualified electrician. And ensure that the electricity supply is switched off before installing or servicing the product.
- 2, The sensor should not be modified in any way. Any modifications mode to this product will immediately invalidate any warranties issued.
- 3, The company does not accept responsibility for any consequences resulting from unauthorized modification of the product.
- 4, The sensor should be connected to a stable power supply of 220/240Vac 50Hz.
- 5, Microwaves cannot pass through metal or brick walls if thicker than 20cm. They will pass through thinner walls but there will be some attenuation.
- 6, Installation inside a glass or plastic housing will result in a reduction of detection sensitivity. Expect a reduction of approximately 20% for every 3mm of thickness.

## **Installation & Wiring**




The sensor has 4-position terminal block as Pic 1: L(Phase) N(Neutral) L' (Switched phase / control)

Pic 1

The sensor is designed for installation at 1~4m in height.

Suggested mounting height: 1~1.8m (Wall mounting), 2.5~4m (Ceiling mounting).

#### To connect several standard ballasts or LED drivers to 1 sensor, the wiring is as Pic 2 or Pic 3.



## Settings

Detection area, hold time and daylight sensor can be set using DIP switches on the sensor. Note that reducing the detection area will also reduce the sensitivity.

1, Detection area	
I: up to 8m	ON 123
II: up to 6m	
III: up to 4m	$\begin{array}{ c c c c c } \hline & & \hline & & \hline \\ \hline & & & \hline \\ \hline \\$
IV: up to 3m	III         ●         ○         ●         50%           IV         ○         ●         25%
V: up to 2m	OFF V 0 0 0 10%
2, Hold time	
Refers to the time period the lamp remains at 100% illumination after no motion detected.	
l: 10s	
II: 30s	
III: 90s	III ● ○ ● 90s
IV: 3min	IV O O 3min V O O 20min
V: 20min	
VI: 30min	VI 0 0 30min
3, Daylight sensor	
The sensor can be set to only allow the lamp to illuminate below a defined ambient brightness threshold. The settings are as follows:	
I: Disable*	ON 123
II: 50lux, twilight operation	
III: 30lux, twilight operation	
IV: 10lux, darkness operation only	
V: 5lux, darkness operation only	IV         O         O         10lux           OFF         V         O         O         5lux
*When set to Disable mode, the daylight sensor will switch on the lamp when motion is detected regardless of ambient light levels.	

# FAQ

Question	Cause	Remedy
The load will not illuminate.	Incorrect daylight sensor setting selected.	Adjust setting.
	Load has failed.	Replace load.
	Power is switched off.	Switch on
	Continuous movement in the detection area.	Check detection area setting.
The load is permanently illuminated.	The lamp (containing sensor) is installed in an area too close to reflective surfaces, i. e. metal, glass or concrete walls.	<ol> <li>Make sure installation area suitable with at least 30cm space between lamp and surrounding reflective surfaces.</li> <li>Reduce sensitivity (detection area).</li> </ol>
The load will not illuminate despite movement.	Speed of moving object is not in the range of $0.5 \sim 3m/s$ or the detection radius is too small.	Check detection area setting.

Shenzhen Merrytek Technology Co., Ltd 4F, Building A, Wenfu Area, No. 1 Industry Park Fenghuang, Fuyong, Baoan, Shenzhen, China, 518103. www. merrytek. com sales@merrytek.com